

## FLOORING INSTALLATION INSTRUCTIONS

### SHEET VINYL FLOORING

Intended for Majestic Phthalate Free Sheet Vinyl Collection



#### Recommended Adhesives:

- **TAJ-1095 Pressure Sensitive Adhesive:** Maximum 10.0 lbs. of moisture per 1,000 sf / 24 hours per ASTM F1869 Calcium Chloride Tests or a max RH of 95% per ASTM F2170 In Situ Relative Humidity Test. pH of 5-12 is acceptable.
- **TAJ Eco Bond Spray Adhesive:** Maximum 8.0 lbs. of moisture per 1,000 sf / 24 hours per ASTM F1869 Calcium Chloride Tests or a max RH of 90% per ASTM F2170 In Situ Relative Humidity Test. pH of concrete shall be <11.
- **Mapei 2-Part Epoxy or Urethane Hard Set Adhesive:** Follow adhesive's manufacturer guidelines for use with sheet vinyl.

To determine the appropriate adhesive for an installation, consult your TAJ Sales Representative or contact TAJ Customer Service: (888) 652-2111 | [info@tajflooring.com](mailto:info@tajflooring.com)

#### Job Site Conditions:

The installation of flooring should be scheduled after the work of all other trades has been completed. Areas to receive resilient flooring shall be clean, adequately lit, fully enclosed, weather tight, and climate controlled by a permanent HVAC system for at least 10 days prior to installation and thereafter to provide a constant temperature. Proper acclimation of the room, substrate, flooring materials and adhesives at a constant and maintainable temperature is critical to the success of the installation process. Temperature variation before during and for the first 48 hours after installation can impact adhesive cure time, affect the size of the flooring material, and increase the potential for indentation and or adhesive displacement. The substrate, flooring materials and adhesive are required to be acclimated within the areas of intended installation at a constant temperature between 65°F to 85°F for 48 hours prior to installation. The selected temperature should be maintained in areas to receive flooring with the building's permanent HVAC system. Salamanders and other temporary heating or cooling devices should not be used. The constant temperature held during acclimation and installation should be maintained for 48 hours following installation, thereafter the interior space should maintain room temperatures in the range of 55° to 85° F. Flooring installed with TAJ-1095 adhesive shall not be exposed to heavy traffic or heavy rolling loads for 24 hours following completion. No maintenance procedures should take place until the adhesive has cured for a minimum of 72 hours. If emergency conditions require the movement of equipment or furniture, the flooring should be protected with heavy planks or a minimum of ½" thick plywood to prevent damage.

#### Storage and Handling:

Upon receipt of the material, remove from crates or skids to fully inspect the material so all rolls can be viewed and inspected for any shipping damage. Contact TAJ Flooring, Inc. immediately with any material issues. Store rolls vertically on a clean level surface. Avoid laying rolls on their sides for long periods of time. When more than one roll is to be installed, make sure to organize the rolls in such a way that they will be installed in sequential order with all sheets running the same direction. If material from more than one production lot is being used, make certain the project is laid out so that no rolls from different production lots are installed adjacent to one another. Flooring materials and adhesives should be on site within the areas of intended installation for a minimum of 48 hours prior to installation allowing materials to acclimate.

#### Concrete Substrate Requirements:

Concrete substrate shall conform to requirements of ASTM F710-05 (Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring). Concrete subfloors shall be steel troweled finished smooth, flat and level. Concrete shall be wet cured for a minimum of 30 days to 3,500 psi. Flatness of concrete shall be  $\pm 1/32$  in a 10'-0" radius. Do not apply any type of coatings, surface sealers, hardeners, or curing membranes to the surface of the concrete. These materials will prevent proper bond of the floor covering adhesive. Minor cracks, chips, and spalls shall be patched with premium quality cement-based patching materials. Level high spots by grinding or sanding. [continue to page 2]

## FLOORING INSTALLATION INSTRUCTIONS

### SHEET VINYL FLOORING

Intended for Majestic Phthalate Free Sheet Vinyl Collection



Any required leveling shall be done with cement-based underlayment, minimum 3,500 psi, i.e., Ardex or Mapei. Patching and underlay material shall be applied in strict accordance with the manufacturer's specifications and installation instructions.

If the concrete is contaminated with any type of sealer, hardener, curing membrane, paint, oil, grease, adhesives, and any other type of penetrating material it should be removed thoroughly by bead blasting. Sanding is not adequate, and chemicals should not be used to accomplish removal. After concrete preparation has been completed, sweep and vacuum surface thoroughly to remove all miscellaneous dirt and contaminants. It is possible that joints of existing resilient flooring may telegraph through. This is common and not a product defect. Ink, markers, and paint on substrate must be removed by sanding to prevent bleed through and staining of the sheet flooring. Sealing and/or skim coating is not a substitute for sanding.

#### Approved Substrates:

Suitable substrates include properly prepared concrete, concrete-based underlayments, properly prepared lightweight concrete (primed with universal primer), minimum 3/8" APA graded smooth sanded plywood, terrazzo (properly prepared with all waxes and surface finishes removed), concrete radiant heated subfloors that do not exceed 85° F. Particleboard, chipboard, flake board, hard board and gypsum based underlayments ARE NOT suitable substrates for installation of vinyl flooring. Contact TAJ Flooring for recommendations regarding all other types of substrates.

#### Installation:

Roll out sheet material with pattern surface up making certain materials are running the same direction. This process will allow material to relax and acclimate to building conditions as well as provide tile for final material inspection. Material should be allowed to relax for a minimum of 24 hours prior to fitting, bonding, and seaming.

- Inspect all sheet material carefully to verify that proper colors are installed in specific areas. Also, do not mix dye lots in the same area. Do not install any material with visible defects. Side seams shall be lapped a minimum of 1" and end seams a minimum of 2". Double cut through side and end seams using metal straight edge prior to adhesive bonding. Fold back sheet of approximately halfway. Apply adhesive. Please note adhesive instructions on the adhesive container.
- Roll flooring into adhesive with a 100 lb. roller immediately upon installation of flooring. Once rolled, the floor is ready for immediate use.
- After sheet vinyl has been installed for a minimum of 1 hour, you can then proceed with the welding of all side and end seams. Sheet Vinyl should be heat welded with corresponding heat weld.
- When heat welding, it is recommended it be done by experienced personnel with a minimum of 5+ years' experience or Master Mechanic certification. Leister or Zinser heat welding equipment is recommended.
- When trimming weld rod following placement of the weld on sheet products with heavy wood grain emboss, TAJ Flooring recommends using a WDD18M Mozart Trimming Knife. The Mozart knife will allow for accurate trimming without damage to the emboss of the sheet flooring.
- Review and follow all instructions associated with the adhesive selected for the unique site conditions of the project.

#### Hospital Beds:

If TAJ sheet vinyl flooring is to be used in patient rooms, special care must be taken in the area under the beds and heavy equipment. Hard setting 2-part adhesive systems such as Mapei-G-15 (Epoxy), G-19 (Urethane), or G-21 (Urethane) give the best results of limiting residual indentation and should be used in these instances. Follow adhesive manufacturer's instructions for use.

## FLOORING INSTALLATION INSTRUCTIONS

# SHEET VINYL FLOORING

Intended for Majestic Phthalate Free Sheet Vinyl Collection



### Protection:

Careful attention should be taken to protect and prevent any unnecessary matters as it relates to the sports flooring including:

- The floor is designed to properly support a static load of 175psi. Furniture, equipment, and rolling loads should not exceed these limits. If they do, legs of such equipment and furniture should be properly supported to prevent damage to tile or planks. Protect floor surface with wood or sheets of plywood whenever heavy equipment or furniture must be moved.
- Chair pads are recommended under chairs with roller casters.
- Felt pads are recommended under chairs with sharp or unprotected edges to prevent scratching.

For more information, contact your TAJ Sales Representative  
or TAJ customer service: (888) 652-2111 | [info@tajflooring.com](mailto:info@tajflooring.com)

V.052023



Scan or [click here](#) to access  
technical information including  
specifications, full warranty,  
maintenance guides,  
certifications and more.